

Directions

- Rust treat all bolts** before assembling.
- Join parts **A** to **C**, using **E**.
- Join parts **B** to (**A** and **C**), using **D**.
- Position stencil:**
 - Use the supplied YD-PCF1A-C backplates stencil.
 - Tape to the bulkhead/door backboard, keeping it level.
- Mark holes:** Use a centre punch through the stencil to mark where you will drill.
- Drill holes:**
 - Start with a 10mm pilot hole.
 - Enlarge to 16.8mm with a standard bit or the YD PC-F1A drill bit.
- Fit clips:** Insert **G** using the YD PC-F1A tapping bit (available from our website).
- Fit clips:** Insert **F** into **C** by hand.
- Install product:** Tap clips fully into place.

Quad Safety Harness Storage Holder (HR-HLD-4)			
A		ARM	2x
B		SUPPORT ARM	2x
C		BACKPLATE	1x
D		M6X20 BOLT	4x
E		M6X40 BOLT	2x
F		YD-PCM2H-C	5x
G		YD-PCF1A-C	5x

Tools and Materials

- Rust protection spray or coating
- Allen key (no. 5.5)
- YD-PCF1A-C stencil (supplied)
- Tape
- Levelling device (if needed)
- Centre punch
- Drill with:
 - 10mm bit (increase to this)
 - 16.8mm or YD PC-F1A drill bit
- YD PC-F1A tapping bit

