

Directions

1. **Rust treat all bolts** before assembling.
2. Join parts **A** to **C**, using **D**.
3. Join parts **B** to **C**, using **D**.
4. **Position stencil:**
 - Use the supplied YD-PCF1A-C backplates stencil (same for top and bottom).
 - Tape to the bulkhead/door backboard, keeping it level.
5. **Mark holes:** Use a centre punch through the stencil to mark where you will drill.
6. **Drill holes:**
 - Work your way up to a 10mm pilot hole
 - Enlarge to 16.8mm with a standard bit or the YD PC-F1A drill bit.
7. **Fit clips:** Insert **F** using the YD PC-F1A tapping bit (available from our website).
8. **Install product:** Tap clips fully into place.

Triple Product Bottle Storage Holder (PB-HLD-3)			
A		TOP PIECE	1x
B		BOTTOM PIECE	1x
C		BACKPLATE	2x
D		M6X40 BOLT	8x
E		YD-PCM2H-C	8x
F		YD-PCF1A-C	8x

Tools and Materials

- Rust protection spray or coating
- Allen key (no. 5.5)
- YD-PCF1A-C stencil (supplied)
- Tape
- Levelling device (if needed)
- Centre punch
- Drill with:
 - 10mm bit (increase to this)
 - 16.8mm or YD PC-F1A drill bit
- YD PC-F1A tapping bit

